

# Parcelcube 900XL SN-1

The dimensioning system that logistics and POS desks have been missing!

## Where can it be used?

### Receive

- (Re)Check of transport costs
- Dimensioning for optimal handling

### Store

- Use Dimensional to allow optimal storage:
  - Warehouse location
  - Type: Shelving, Racks, Floor

### Deliver

- Determines transport fares for cartoon delivery:
  - Optimize Packages
  - Provide the measurements to transporter
- Use for palletizing

### POS

- At point of sales desks and Service Kiosks

## How does it work?


Simply place the parcel on the scale. Press a button or read a barcode and Parcelcube will capture the dimensions and weight of the parcel. Data is captured in less than one second – accurately and efficiently!

The **SN-1** model includes a measuring, weighing scale with accurate and reliable four load cell construction, weight display for actual weight, barcode scanner (optional).

**Accurate & efficient!**  
Easy integration



# Parcelcube – the solution for both inbound and outbound logistics



## Why Parcelcube?

- accurate and efficient
- reliable and fast (data captured in less than 1 sec.)
- 5-minute set-up
- user-friendly PC interface
- boost productivity
- reduce costly manual data entry and errors
- simply click to capture and/ or transfer data
- priced right, even for small companies

## 900XL SN-1 specifications

<b>Physical</b>	
Dimensions, L x W x H	88 x 88 x 113 cm 34.6 x 34.6 x 44.5 in
Weight	17 kg / 37.5 lbs
<b>Measuring capacity</b>	
Minimum, L x W x H	4 x 4 x 2 cm 1.5 x 1.5 x 0.8 in
Maximum, L x W x H	82 x 82 x 94 cm 32 x 32 x 37 in
Dimensional increment	0,1cm/1,0cm 0,004/0,04 in
<b>Weighing capacity</b>	
Minimum	0.05 kg / 0.11 lbs
Maximum	55 kg / 120 lbs
Increment	0.05 kg / 0.11 lbs
<b>Other</b>	
Power Supply	100–240 VAC 50/60 Hz
Measuring sensor	Ultrasonic
Weigh sensor	4 x load cell
Data output	CSV / XML / HTTP
User interface	Parcelcube client
PC connection	USB
Operating temperature	+15... +30 °C
<b>Accessories</b>	
Panel PC	
Barcode reader	
Camera + camera interface	

## User-friendly PC interface

The Parcelcube™ unit includes as standard user-friendly PC software. A guided installation takes less than two minutes. The PC interface (software) has all the features required for inbound, outbound and POS desk operations.

## PC software features

- imperial and metric units
- communication
  - real-time data transfer (API) as standard
  - offline .csv file
  - Copy F9: Click to transfer to data to 3<sup>rd</sup> party without IT integration > easily configure order of data output (dimensions X–Y–Z and weight).
- item counting and stacking
- 7 user-defined values for data entry
- high/ low resolution, 1 mm, 3 mm or 1 cm
- auto calibration
- camera feature

## Maintenance

The Parcelcube™ dimensioning systems require no expensive on-site calibration or maintenance, as 95% of maintenance and support is done remotely by our technical team. In the event of mechanical damage, we normally guide a local electrician to change the part, cost-efficient and easy! A calibration cube is supplied, and the operator can easily calibrate the scale in less than a minute.



contact@parcelcube.com

www.parcelcube.com